



UFP-00/Universal Flattening Base Mix Chart

Note: Results may vary with use of UFP-00. Spray a sample and always verify the gloss meets your needs *before* proceeding. Not recommended to lower gloss below 10° with UFP-00.

UFP-00 will increase the VOC of certain 275 VOC product lines above the <275 VOC limit, and therefore are not included in this reference chart.

Nitrocellulose Lacquers-Clear

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
WCL-0090	60°	2.7	79	75
WCL-0060	30°	1.8	53	51
WCL-0030	10°	7.8	230	218

BASE 120 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
HSL-0090	60°	2.4	71 ml	68 g
HSL-0060	25°	3.3	97 ml	92 g
HSL-0025	10°	7.5	221 ml	210 g

BASE 120 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
HBL-0090	60°	2.2	66 ml	62 g
HBL-0060	30°	7.4	219 ml	208 g
HBL-0030	10°	2.3	68 ml	64 g

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
700-1290	60°	2.8 fl oz	83 ml	79 g
700-1260	30°	2.8 fl oz	83 ml	79 g
700-1230	20°	1.7 fl oz	49 ml	46 g
700-1220	10°	2.8 fl oz	83 ml	79 g



Nitrocellulose Lacquers-Pigmented

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
WL-1090	60°	2.7	80	76
WL-1060	30°	5.3	158	150
WL-1030	10°	5.7	169	161

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
WL550-1060	30°	2	59	56
WL550-1030	20°	4	117	111
WL550-1020	10°	5.3	157	149

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
400-1290	60°	1.9	56	53
400-1260	30°	4	121	115
400-1230	20°	1.9	56	53
400-1220	10°	4.8	141	134

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
400-2490	60°	5.1	151	143
400-2460	20°	6.9	203	193
400-2420	10°	4	117	111



Precatalyzed Lacquers-Clear

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
PC-0490	60°	2.1	63	60
PC-0460	30°	4.1	121	114
PC-0430	20°	5	148	140
PC-0420	10°	5	148	140

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
PC-0090	60°	2.4	71	67
PC-0060	30°	3.7	110	104
PC-0030	20°	2.5	74	70
PC-0020	10°	4.5	133	126

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
NXC-0760	30°	5	144	137
NXC-0730	20°	2.5	75	71
NXC-0720	10°	5.8	171	162

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
UL-0090	60°	4.4	129	122
UL-0060	30°	8.5	251	238
UL-0030	20°	4.6	137	130
UL-0020	10°	7.7	227	215



Precatalyzed Lacquers-White

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
NEXW-1590	60°	2	65	61
NEXW-1560	30°	2.9	86	81
NEXW-1530	20°	2.5	72	68
NEXW-1520	10°	5.8	173	164

BASE 120 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
UL-1030	20°	6	179	170
UL-1020	10°	6	179	170

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
PCW550-1060	30°	4.6	138	131
PCW550-1030	10°	6.2	183	174

Conversion Varnishes-Clear

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
AFCVRS-0290	60°	2.7	79	75
AFCVRS-0260	30°	7.3	216	205
AFCVRS-0230	20°	4.4	129	122
AFCVRS-0220	10°	7.8	232	220

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
UCV-0090	60°	5.5	164	156
UCV-0060	30°	4	122	115
UCV-0030	20°	7	212	201
UCV-0020	10°	5	151	143



Conversion Varnishes-Pigmented

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
ASTW-1090	60°	3.2	94	89.2
ASTW-1060	30°	9	262	248.5
ASTW-1030	20°	9.77	289	274.1

BASE 128 fl oz	CHANGE TO	Fluid Ounces needed of UFP-00	Milliliters needed of UFP-00	Grams needed of UFP-00
UCV-1090	60°	2.2	64	61
UCV-1030	10°	7.6	225	214